



**Jeep TJ Sidebars
Part # 34300**

Parts List

- 2-TJ Sidebars(RT & LT)
- 2-10" Anti-Slip Strips
- 16-3/8 x 1 Self-Tapping Bolts
- 8-3/8 Flatwashers

Installation Instructions

1. With some help, position the sidebar on frame. The front pad should just touch the body bracket.
2. Adjust the sidebar up to the body, so you have about 3/4" from the bottom of the body. Clamp or secure the sidebar to the frame for marking holes.
3. mark all 8 holes on the frame, then remove sidebar, use a small drill first(3/16") to drill into frame, then enlarge to 5/16"
4. Install all self-tapping bolts into frame(use oil or a tap cutting oil. After threads are cut into frame, remove the bolts and re-install sidebar.
5. If necessary, use the 3/8 flatwashers between the mounting pad and frame to level sidebar.
6. Align and tighten all hardware.
7. Install the anti-slip strip to the round tube.
8. For extreme duty, the mounting pads should be welded to the frame. Welding spots are shown on page 2. The powder coating must be sanded off at weld points, and touched up with paint after welding.

WILDERNESS PRODUCTS

TJ SIDEBARS

PART # 34300



PAGE 1 OF 2

